

# SERVICE LETTER

## OPERATORS AND MAINTENANCE MANUAL FOR ROTAX, TYPE 912 SERIES SL-912-008

### Repeating symbols:

Please, pay attention to the following symbols throughout the Service Bulletin emphasizing particular information.

- ▲ **WARNING:** Identifies an instruction, which if not followed, may cause serious injury or even death.
- **ATTENTION:** Denotes an instruction which if not followed, may severely damage the engine or could lead to suspension of warranty.
- ◆ **NOTE:** Information useful for better handling.

### 1) Planning information

#### 1.1) Engines affected

All versions of the engine type:  
912 (Series/pre-series)

#### 1.2) Concurrent ASB/SB/SI und SL

none

#### 1.3) Reason

Upon type certification of the engine type ROTAX<sup>®</sup> 912 S and in view of necessary updating and standardization the Operator's Manuals and Maintenance Manuals for each engine type have been combined into one Operator's and one Maintenance Manual.

In the course of standardization the voluminous Maintenance Manuals have been split up according to purpose into a Line Maintenance and Base Maintenance Manual.

#### 1.4) Subject

Operators and Maintenance Manual for ROTAX<sup>®</sup> Type 912 Series

#### 1.5) Compliance

RECOMMENDED

For technical reasons we strongly advise to update the documentation to the latest revision.

#### 1.6) Approval

not required

AUFGEHOBEN (ersetzt durch SB-25T-000/912-000/914-000 letzte gültige Ausgabe)  
CANCELLED (superseded by SB-25T-000/912-000/914-000 latest edition)