

SERVICE LETTER

List of Applicable Publications for ROTAX_® Aircraft Engines

ATA System: 00-00-00 GENERAL NOTE

1) Planning information

To obtain satisfactory results, procedures specified in this publication must be accomplished with accepted methods and prevailing legal regulations.

BRP-Rotax GmbH & Co KG, cannot accept any responsibility for the quality of work performed in accomplishing the requirements of this publication.

1.1) Applicability

All versions of $ROTAX_{\circledR}$ engine types:

Engine type	Serial number
912 A	(Series / Pre-series)
912 F	(Series / Pre-series)
912 S	(Series / Pre-series)
912 iS	(Series / Pre-series)
912 iS Sport	(Series / Pre-series)
912 iSc Sport	(Series / Pre-series)
912 UL	(Series / Pre-series)
912 ULS	(Series / Pre-series)
915 iS A	(Series / Pre-series)
915 iSc A	(Series / Pre-series)
915 iSc B	(Series / Pre-series)
914 F	(Series / Pre-series)
914 UL	(Series / Pre-series)
2-stroke aircraft engines	(Series / Pre-series)

1.2) Concurrent ASB/SB/SI and SL

None

1.3) Reason

Reference to the list of applicable publications (LOAP) in accordance with Part 21A.57 "Instruction for continued airworthiness" issued by BRP-Rotax GmbH & Co KG.

1.4) Subject

List of Applicable Publications for ROTAX® Aircraft Engines.

SERVICE LETTER

1.5) Compliance

For continued airworthiness keep the documentation to the latest valid revision level in accordance with the list and the information available on the $ROTAX_{@}$ AIRCRAFT ENGINES website.



Non-compliance with these instructions could result in engine damages, personal injuries or death!

1.6) Approval

None.

2) Material Information

None

3) Accomplishment / Instructions

The up-to-date LOAP is available for export on the ROTAX® Aircraft Engines website.

Step	Procedure
1	Open www.flyrotax.com
2	Select Services -> Technical Documentation.
3	Select your search criteria.
4	Download (or print) the overview according to the relevant selection by using the "Export Results" function on the website.

NOTE:

The current documentation (current issue) or relevant revisions (replacement pages) are also available at any ROTAX® Authorized Distributor or their independent Service Centers in printed version on request. A list of all ROTAX® Authorized Distributors or their independent Service Centers is provided on www.flyrotax.com.

Symbols used

For meaning of the symbols used in this document, see chapter >Safety< in the latest Operators Manual of the respective engine type.

Translation into other languages might be performed in the course of language localization but does not lie within ROTAX® scope of responsibility.

In any case the original text in English language and the metric units are authoritative.

d06369.fm