

## USE OF THE ROTAX<sub>®</sub> SUPPLIED AIRBOX FOR ALL ROTAX<sub>®</sub> ENGINE TYPE 912 UL (SERIES) SB-912-044UL



## **Repeating symbols:**

Please, pay attention to the following symbols throughout this document emphasizing particular information.

- ▲ WARNING: Identifies an instruction, which if not followed, may cause serious injury or even death.
- CAUTION: Denotes an instruction which if not followed, may severely damage the engine or could lead to suspension of warranty.
- ♦ NOTE: Information useful for better handling.

## 1) Planning information

## 1.1) Engines affected

All versions of the engine type:

- 912UL all

if they are to be operated or retrofitted with the original ROTAX<sub>®</sub> airbox part no. 867756.

♦ NOTE: Engine types 912 ULS, 912 ULSFR are not affected, as the airbox has been available for these types since the beginning of serial production.

For complete instructions and compliance to this Service Bulletin refer to

Service Bulletin SB-912-044, latest edition section 1.2 onward.

NOTE: Section 1.6) Approval: Is not required for engines of the type UL (series).
Section 3) Accomplishment: In addition: persons with adequate type-specific training.

103384

Copyright - ROTAX®